MODEL 163

The convenience control allows the driver to operate the electrical seat adjustment, the power windows, the electric vent windows, the electric outside rearview mirror as well as the electric sliding/pop-up roof or the electric lamella sliding roof when the ignition is switched off.

To achieve this, the all-activity module (AAM) (N10) switches to the corresponding loads via the convenience relay (F1k14) circuit 30 .

As of 12.99 the vehicle is equipped with its own convenience relay for seat adjustment (relay 1, F2k1). In addition the status of the convenience control via CAN is transmitted to the extended activity module (EAM, N10/1).

Conditions for control actuation

On all-activity module (AAM) (N10) configured for I up to 11.99:
The convenience actuation becomes active as soon as
- D Circuit 15 ON is recognized

When circuit 15 is switched off, the convenience actuation is deactivated after a door is opened

Otherwise

The convenience actuation is active in the following cases:
- D Circuit 15c ON
- D A front door is open
- D The remote control key is removed, however, the doors are not yet opened

In both cases the convenience actuation remains active for 5 min.

i Switch-on condition for circuit 15c

When the remote control key is inserted into the ignition lock, circuit 15c is switched on when the key is turned out of the zero position. Circuit 15c switches off only after the remote control key is removed from the ignition lock

	Electric seat adjustment without memory, function		GF91.29-P-0003GH
	Electric seat adjustment with memory, function	as of 12.99	GF91.29-P-0002GH
	Convenience control, function	for electrical seat adjustment as of 12.99	GF91.29-P-2013GK
	Power windows, function		GF72.29-P-0003GH
	Power tilting/sliding roof (SR), function		GF77.20-P-0001GH
	Electrically adjustable outside rearview mirrors, function		GF88.79-P-0005GH
	Electric vent windows, function		GF67.39-P-1000GH
	Extended activity module, location/purpose/design	as of 12.99	GF54.21-P-4107GK